
F3228, F3229 INSTALLATION INSTRUCTIONS



WARNING DISCONNECT POWER BEFORE RELAMPING OR WIRING THE FIXTURE. READ ALL INSTRUCTIONS COMPLETELY BEFORE STARTING INSTALLATION.



1. Remove the fixture, parts and parts bag(s) from the carton.

NOTICE:

Before discarding the carton, double check to make certain that all parts are found.


FIXTURE INSTALLATION

- 1. (Starting at the back) thread the 2 mounting screws into the mounting bar. (The green screw is in the front) Attach the mounting bar to the outlet box.
- 2, thread the lead wire and ground wire though the stem, screw ring and canopy, then assemble them on fixture.
- 3. Fasten the ground wire to the green or bare copper wire in the outlet box or to the green screw on the crossbar.

Never fasten the ground wire to the black or "hot" wire! Failure to follow this instruction could result in serious injury or death!

4. Fasten the white fixture lead to the white wire in the outlet box. Fasten the wires together with an approved fastener (wire nut). Starting about 1' below the fastener, tightly wrap the connection with electrical tape so that the connection seals the end of the fastener.

Make sure that there is no exposed wire or strands that could cause a dangerous short circuit !



- 5. Connect the black fixture lead to the black wire in the outlet box. Fasten the joined wires as in step 4.
- 6. Fasten the canopy to ceiling use ball nuts.
- 6. Install the lamps (light bulbs). NOTE: This fixture F3228 is rated for Max 60 watt type B lamps. fixture F3229 is rated for Max 100 watt type A lamps or early electric lamp.

WARNING DO NOT EXCEED RECOMMENDED WATTAGE!

- 7, Install the glass to fixture use allen screw and then fix the cage to fixture use nut.
- 8. Restore power to circuit at breaker or fuse box.

