C1350 INSTALLATION INSTRUCTIONS



Λ

WARNING

DISCONNECT POWER BEFORE RELAMPING OR WIRING THE FIXTURE. READ ALL INSTRUCTIONS COMPLETELY BEFORE STARTING INSTALLATION.

Λ

CAUTION

- TO AVOID THE RISK OF FIRE OR SHOCK, FIXTURE MUST BE INSTALLED IN COMPLIANCE WITH ALL APPLICABLE NATIONAL AND LOCAL ELECTRICAL/BUILDING CODES.
- INSTALLATION AND MAINTENANCE OF THIS UNIT REQUIRES AN ELECTRICIAN OR CERTIFIED FACTORY TRAINED TECHNICIAN.
- If an existing fixture is being replaced, remove it and note to which of the wires in the outlet box the fixture was attached.
 DO NOT SEPARATE ANY OTHER WIRES THAT MAY BE IN THE BOX. DO NOT DAMAGE THE INSULATION OF OLDER WIRING.
 In regular circumstances the BLACK wire will be the "Hot" lead and the WHITE wire will be the "Neutral" or "Common" lead.
 A GREEN or BARE COPPER wire is the "Ground". In older buildings it is always good practice to reconfirm the polarity of the wiring.

NOTICE

- The important safeguards and instructions outlined on this sheet cannot cover all possible conditions and situations that may occur. It must be understood that common sense, caution and care are factors that cannot be built into any product.

 Caution and care must be supplied by the person(s) installing, operating and caring for this lighting fixture.
- This fixture is designed to be mounted on a correctly installed standard round or octagon box or a through wiring box
 with a plaster frame. The box must be securely mounted to the structure of the building.
 The crossbar and hardware supplied should be used. Directly mounting the fixture to the outlet box may make it impossible to
 correctly align the fixture.
- For your safety be certain that all circuit breakers controlling outdoor lighting and equipment are GFI breakers.

FIXTURE PREPARATION

Remove the fixture, parts and parts bag(s) from the carton.

NOTICE:

Before discarding the carton, double check to make certain that all parts are found.

FIXTURE INSTALLATION

- 1. Attach the adjustable crossbar to the outlet box. (The green screw should face the floor).

 NOTE: The screws are set to be correct for most installations. In some cases the screws will have to be adjusted
- Fasten the ground wire to the green or bare copper wire in the outlet box or to the green screw on the crossbar.



WARNING


Never fasten the ground wire to the black or "hot" wire! Failure to follow this instruction could result in serious injury or death!

1 7/3/2020

3. Fasten the white fixture lead to the white wire in the outlet box. Fasten the wires together with an approved fastener (wire nut). Starting about 1' below the fastener, tightly wrap the connection with electrical tape so that the connection seals the end of the fastener.




Make sure that there is no exposed wire or strands that could cause a dangerous short circuit!




- 4. Connect the black fixture lead to the black wire in the outlet box. Fasten the joined wires as in step 3
- 5. Using the end nuts, loosely fasten the fixture to the outlet box. Rotate and align the fixture as necessary. Tighten the end nuts.
- **6.** Adjust the hex nut on the nipple so that 3/8" is exposed at the end. Thread the nipple into the hex coupling that is centered on the socket bracket. Tighten the nut against the coupling.
- 7. Install the lamps (light bulbs). NOTE: This fixture is rated for Max60 watt type A-15 (fan) lamps.



- 8. Place the center glass into the fixture.
 Using the soft washer and the cap nut secure the glass in place.
- 9. Restore power to circuit at breaker or fuse box.





2 7/3/2020